

[Outdoor](#)[Husky](#)[Husky A300](#)[Error Codes](#)

Husky A300 Error Codes



Robots are complex. Issues can occur. Examine the following information for possible methods to recover from an unexpected state of Husky. See [Components Overview](#) for detail on button locations and vehicle state indicators. Contact our support team at support@clearpathrobotics.com if the issue persists.

Error Codes

This section includes a full list of the possible error codes along with troubleshooting guidance for each one.

E100 - Critical errors

E110 - Main Contactor Error!

E113 - Battery Out of Range!

E116 - E-Stop Contactor Error!

E117 - Brake Contactor Error!

E120 - Motor 1 Voltage Range Error!

E121 - Motor 2 Voltage Range Error!

E122 - Motor 3 Voltage Range Error!

E123 - Motor 4 Voltage Range Error!

E124 - Motor Voltage Range Error!

This is a general error for a voltage issue on any motor.

E140 - User Power Contactor Error!

E150 - 24V Aux Power Fail!

E151 - 12V Aux Power Fail!

E152 - 12V1 Sys Power Fail!

E153 - 12V2 Sys Power Fail!

E154 - 12V A User Power Fail!

E155 - 12V B User Power Fail!

E156 - VBAT User Power Fail!

E157 - 24V User Power Fail!

E160 - Power Supply Failure!

This is a general error which is set for any of the power fail errors.

E170 - VBAT User Power Fuse Tripped!

E171 - 24V User Power Fuse Tripped!

E172 - 12V A User Power Fuse Tripped!

E173 - 12V B User Power Fuse Tripped!

E174 - Expansion Power Fuse Tripped!

E800 - Low priority errors

E810 - Fan 1 Below Minimum Speed!

E811 - Fan 2 Below Minimum Speed!

E812 - Fan 3 Below Minimum Speed!

E813 - Fan 4 Below Minimum Speed!

E814 - Fan 5 Below Minimum Speed!

E815 - Fan 6 Below Minimum Speed!

E816 - Fan 7 Below Minimum Speed!

E817 - Fan 8 Below Minimum Speed!

E820 - Fan Below Minimum Speed!

This is a general error for any fan.

E830 - Fan 1 Above Maximum Speed!

E831 - Fan 2 Above Maximum Speed!

E832 - Fan 3 Above Maximum Speed!

E833 - Fan 4 Above Maximum Speed!

E834 - Fan 5 Above Maximum Speed!

E835 - Fan 6 Above Maximum Speed!

E836 - Fan 7 Above Maximum Speed!

E837 - Fan 8 Above Maximum Speed!

E840 - Fan Above Maximum Speed!

This is a general error for any fan.

*Last updated on **May 14, 2026***